





- If the first board is up against a wall this will need to be face fixed, finishing the Durafix screw head 5mm below the surface
- Insert the Multi-Spacers in the gap between the first and second board with a 6mm spacing
- Push the board up to the multi spacer





- Lay the DuoFix Side-Fixing Guide onto the board, with the raised sections on the underside of the guide set on either side of the board
- Push the ends of the Guide tight up the sides of the decking board





- Turn the thumbscrew clockwise to set the size to the board width
- This may need to be adjusted when fixing the boards





- Using a drill with the DuoFix Driver Bit, fix the outside edge of the board using a DuraFix fixing through the central hole in the Guide
- Apply pressure to the DuoFix Guide whilst fixing
- Stop when the Driver Bit collar touches the Guide





- Fix the back edge of the board in the same manner
- Fix the board to the remaining joists using a fixing on both sides of the board, fixing at every joist intersection





- The diagonal holes are to be used when the central holes cannot be used (i.e. when up against a wall)

millboard.co.uk

© 2021 The Millboard Company Ltd., Millboard®, Lastane®, Durafix®, Lasta-Grip®, DuoSpan®, DuoLift® and the phrase "Live. Life. Outside.™ are protected trademarks Patents and Patents Pending apply to Millboard® products. The company will vigorously defend its patent rights. Due to printing restraints, actual colours may vary from those shown in brochure. This brochure is not to be reproduced or copied without written permission from Millboard directors. Millboard has a policy of continual improvement to specification. Product blend, colours and sizes may change without notice. All sizes and measurements are nominal. Information is correct at time of going to press. Patent numbers include GB 2445714, GB 2449184, USA 8,065,849. CAN 2664329, EU 1951971. Version 260F1SHe – 0121.

