

SINGLE (STANDALONE) DWELLING

Non Wet Areas

Areas other than Kitchens, Bathrooms, Toilets, and Laundries



①	Forté Engineered Timber	
②	Timber Adhesive	Option 1: Selleys Liquid Nails Timberflex Option 2: Mapei Ultrabond Eco S955 1K Option 3: Ardex 480 MS
③	Floor Surface Preparation (if required)	As per Forté Installation Guide (refer to 4.2.3).
④	Epoxy Moisture Barrier (If Required)	As per as per Forté Installation Guide (Refer to 4.2.2.)
⑤	Substrate	Slab-on-grade or suspended concrete or sheet timber.