

SINGLE (STANDALONE) DWELLING

Wet Areas (E3 Alternative Solution Compliance)

Includes Kitchens, Bathrooms, Toilets, and Laundries



① Forté Engineered Timber	With D3 PVA* to joints and caulking sealant to perimeter as per Forté Installation Guide (refer to 5.6.1).
	<i>*Note: if open-plan area, D3 PVA application only applies within 1.5M of sanitary fixtures/appliances.</i>
② Timber Adhesive	Option 1: Selleys Liquid Nails Timberflex Option 2: Mapei Ultrabond Eco S955 1K Option 3: Ardex 480 MS
③ Floor Surface Preparation (if required)	As per Forté Installation Guide (refer to 4.2.3).
④ Epoxy Moisture Barrier (If Required)	As per as per Forté Installation Guide (Refer to 4.2.2.)
	Option 1: Selleys Liquid Nails VBS Option 2: Mapei Planiseal MR Option 3: Ardex WPM 300
⑤ Substrate	Slab-on-grade or suspended concrete or sheet timber.
	<i>Note: particleboard or oriental strandboard are not recommended substrates in wet areas.</i>

Forté E3 Technical Documentations for Submitting to Council

1. [Selleys](#)
2. [Mapei](#)
3. [Ardex](#)

Note: Moisture barriers, surface preparation, and adhesives should be from the same supplier.