



MULTI DWELLING		
Wet Areas (E3 Alternative Solution Compliance)		
Includes Kitchens, Bathrooms, Toilets, and Laundries		
1	Forté Engineered Timber	With D3 PVA* to joints and caulking sealant to perimeter as per Forté Installation Guide (refer to 5.6.1).
		<i>*Note: if open-plan area, D3 PVA application only applies within 1.5M of sanitary fixtures/appliances.</i>
2	Timber Adhesive	Option 1: Selleys Liquid Nails Timberflex Option 2: Mapei Ultrabond Eco S955 1K Option 3: Ardex 480 MS
3	Acoustic Underlay	Forté Acoustic-Mat Underlay (or equivalent) as per Forté Installation Guide (refer to 4.7).
4	Timber Adhesive	Option 1: Selleys Liquid Nails Timberflex Option 2: Mapei Ultrabond Eco S955 1K Option 3: Ardex 480 MS
5	Floor Surface Preparation (If Required)	As per as per Forté Installation Guide (Refer to 4.2.3.)
6	Epoxy Moisture Barrier (If Required)	As per as per Forté Installation Guide (Refer to 4.2.2.)
		Option 1: Selleys Liquid Nails VBS Option 2: Mapei Planiseal MR Option 3: Ardex WPM 300
7	Substrate	Slab-on-grade or suspended concrete or sheet timber.
		<i>Note: particleboard or oriental strandboard are not recommended substrates in wet areas.</i>

Forté E3 Technical Documentations for Submitting to Council

- [Selleys](#)
- [Mapei](#)
- [Ardex](#)

Note: Moisture barriers, surface prepration, and adhesives should be from the same supplier.